



How to turn off Wifi function



To access your modem's settings, open an Internet browser and enter the modem's IP address "192.168.1.1" in the address bar.

In the pop-up window for log-in , type "user" for user name in the first line, and type "admin" for password in the second line.



Click "無線 LAN 設定" (Wireless LAN setting) in the side menu on the left to show more menu items, then click "無線 LAN 共通設定" (Wireless LAN common setting).

